

## C315X Quick Guide

## **Unpacking**


Please make sure the package contains the following items:



# **Product Overview Front Panel**




**Rear Panel** 






### Installation

### Without 86 embedded box in the wall



Mark two fixation holes through wall bracket on the wall, the distance between which is 60mm. Make sure the all cables can be passed from the middle of wall bracket.


Take down the bracket, then using a 5mm hand drill to make the two fixation holes on the wall you marked before.



Use two ST4X20 screws to fix the wall bracket on the wall.

Once the fixation holes are made, insert the two screw fixing seats provided.


### With 86 embedded box in the wall



Make sure all cables in the 86 embedded box. Fix the wall bracket on the 86 embedded box with two M4X30 screws.

## C315X Quick Guide

## **Device Mounting**



## Configuration

- 1. After setting up network and power, press Settings icon, enter System Info, then choose Network to check IP address (DHCP by default).
- 2.Launch web browser and type in the IP address to access web interface, login with username and password.(admin by default)
- 3.Press Account to Register the device with your SIP account.(please refer to user manual for more information)

## **Operation**

#### Make a call

Press Intercom icon to enter the callee's number or room address, then choose Audio or Video mode to call out.

#### Receive a call

When receiving a video call, users can choose Audio or Video key to answer. However, if there is an audio call, users can only press Audio key to pick up.

#### Unlock

During the talk, press the unlock icon in talking interface to unlock the door.


#### Monitor

Press Live View icon to receive the video from indoor IPC or community IPC any time.



## C315X Quick Guide

## **Device Wiring**



#### **Notice Information**

Information contained in this document is believed to be accurate and reliable at the time of printing. This document is subject to change without notice, any update to this document can be viewed on Akuvox's website: <a href="http://www.akuvox.com">http://www.akuvox.com</a> © Copyright 2019 Akuvox Ltd. All rights reserved.

#### AKUVOX (XIAMEN) NETWORKS CO., LTD.

ADD: 10/F, NO.56 GUANRI ROAD, SOFTWARE PARK II, XIAMEN 361009, CHINA www.akuvox.com

